



# BACKLINE & ORCHESTRAL

Rental Solutions For All Musicians



















| Brand      | Model              | Title                           | Image   | Category |
|------------|--------------------|---------------------------------|---|----------|
| Yamaha     | CVP805PE           | Yamaha CVP-805 PE               |    | Keys     |
| Korg       | Minilogue          | Korg Minilogue                  |    | Keys     |
| M Audio    | OXYGENPROMINI      | M-Audio Oxygen Pro Mini         |    | Keys     |
| Access     | Virus TI2 Polar    | Access Virus TI2 Polar          |    | Keys     |
| Akai       | Advance 61         | Akai Advance 61                 |    | Keys     |
| Akai       | MPK249             | Akai MPK249                     |    | Keys     |
| Arturia    | KeyLab 49 MKII -WH | Arturia KeyLab 49 MKII -WH      |  | Keys     |
| Arturia    | KeyLab 49 MKII     | Arturia KeyLab 49 MKII          |  | Keys     |
| Arturia    | KeyStep 37 Pro     | Arturia Keystep Pro 37          |  | Keys     |
| Boss       | FV500L             | Boss FV500L Stereo Volume Pedal |  | Keys     |
| Boss       | FV50L              | Boss FV50L Stereo Volume Pedal  |  | Keys     |
| Korg       | C-340 DR           | C 340 DR                        |  | Keys     |
| CGM        | 125T               | CGM 125T                        |  | Keys     |
| CGM        | 126TCH-BG-BL       | CGM 126TCH-BG-BL                |  | Keys     |
| Cherub     | WTB-005            | Cherub WTB 005 Sustain pedal    |  | Keys     |
| Sequential | Prophet 12         | Sequential (DSI) Prophet 12     |  | Keys     |

|                    |                      |                                 |   |      |
|--------------------|----------------------|---------------------------------|---|------|
| Nord               | 10876                | Nord Electro 6HP                |    | Keys |
| Fender             | Rhodes MK 1          | Fender Rhodes MK 1              |    | Keys |
| Fender             | Rhodes MK 1 Suitcase | Fender Rhodes Suitcase          |    | Keys |
| Fender             | FEND-SP              | Fender Rhodes MK1 Sustain pedal |    | Keys |
| Hammond            | XPK-250B             | Hammond XPK250 Pedal            |    | Keys |
| Hammond            | B3                   | Hammond B3                      |    | Keys |
| Hammond            | B3 Pedal             | Hammond B3 Pedal                |    | Keys |
| Hammond            | EXP-100F             | Hammond EXP100F                 |    | Keys |
| Hidrau             | BC46-BG-BKL          | Hidrau BC46-BG-BKL              |  | Keys |
| Hohner             | Clavinet D6          | Hohner Clavinet D6              |  | Keys |
| K&M                | 13980-200-21         | K&M 13980-200-21                |  | Keys |
| K&M                | 14065-000-55         | K&M 14065-000-55                |  | Keys |
| K&M                | 13820-13701          | K&M 13820-13701                 |  | Keys |
| K&M                | 13824-13710          | K&M 13824-13710                 |  | Keys |
| K&M                | 14080-000-55         | K&M 14080-000-55                |  | Keys |
| K&M                | 13950-100-21         | K&M 13950-100-21                |  | Keys |
| K&M                | 14075-000-55         | K&M 14075-000-55                |  | Keys |
| Kawai              | Novus NV-5S          | Kawai Novus NV5S                |  | Keys |
| Native Instruments | Komplete Kontrol A25 | Komplete Kontrol A25            |  | Keys |

|                    |                          |                             |   |      |
|--------------------|--------------------------|-----------------------------|---|------|
| Native Instruments | Komplete Kontrol S61 MK2 | Komplete Kontrol S61 MK2    |    | Keys |
| Korg               | SP-170S                  | SP 170S                     |    | Keys |
| Korg               | PS-3                     | Korg Damper Control Switch  |    | Keys |
| Korg               | DS-1H                    | Korg DS 1H Sustain Pedal    |    | Keys |
| Korg               | EXP-2                    | Korg EXP 2 Expression Pedal |    | Keys |
| Korg               | KingKORG                 | Korg KingKORG               |    | Keys |
| Korg               | Kronos 2 61              | Korg Kronos 2 61            |    | Keys |
| Korg               | Kronos 2 73              | Korg Kronos 2 73            |    | Keys |
| Korg               | Kronos 2 88              | Korg Kronos 2 88            |  | Keys |
| Korg               | Kronos 2 88 LS           | Korg Kronos 2 88 LS         |  | Keys |
| Korg               | Kronos X 73              | Korg Kronos X 73            |  | Keys |
| Korg               | Kronos X 88              | Korg Kronos X 88            |  | Keys |
| Korg               | M1 61                    | Korg M1 61                  |  | Keys |
| Korg               | M3 61                    | Korg M3 61                  |  | Keys |
| Korg               | M3 73                    | Korg M3 73                  |  | Keys |
| Korg               | M3 88                    | Korg M3 88                  |  | Keys |
| Korg               | MicroKORG                | Korg MicroKORG              |  | Keys |
| Korg               | MicroKORG XL             | Korg MicroKORG XL           |  | Keys |

|      |                                   |                                   |   |      |
|------|-----------------------------------|-----------------------------------|---|------|
| Korg | MS-2000                           | Korg MS 2000                      |    | Keys |
| Korg | nano KONTROL2                     | Korg nano KONTROL2                |    | Keys |
| Korg | Nautilus 73                       | Korg Nautilus 73                  |    | Keys |
| Korg | Korg Opsix Altered FM Synthesizer | Korg Opsix Altered FM Synthesizer |    | Keys |
| Korg | PA-800                            | Korg PA 800                       |    | Keys |
| Korg | PA4X-61                           | Korg PA4X-61                      |    | Keys |
| Korg | PA4X-ORT                          | Korg PA4X ORT                     |    | Keys |
| Korg | PS-1                              | Korg Pedal Switch PS1             |    | Keys |
| Korg | Prologue 8                        | Korg Prologue 8                   |  | Keys |
| Korg | R3                                | Korg R3 37                        |  | Keys |
| Korg | KO-SP280SP                        | Korg Sustain pedal for SP280      |  | Keys |
| Korg | SV-1                              | Korg SV-1                         |  | Keys |
| Korg | Trinity Plus                      | Korg Trinity Plus 61              |  | Keys |
| Korg | Triton Extreme 61                 | Korg Triton Extreme 61            |  | Keys |
| Korg | Triton Extreme 76                 | Korg Triton Extreme 76            |  | Keys |
| Korg | Triton Extreme 88                 | Korg Triton Extreme 88            |  | Keys |
| Korg | Triton Pro                        | Korg Triton Pro 76                |  | Keys |
| Korg | Triton Pro X                      | Korg Triton Pro X 88              |  | Keys |











|          |                        |                                     |   |      |
|----------|------------------------|-------------------------------------|---|------|
| Korg     | Triton Studio 88       | Korg Triton Studio 88               |    | Keys |
| Korg     | XVP-10                 | Korg XVP 10 Expression Volume Pedal |    | Keys |
| Kurzweil | KP-1                   | Kurzweil KP 1 Sustain Pedal         |    | Keys |
| Kurzweil | X-PRO MG               | Kurzweil X PRO MG                   |    | Keys |
| M Audio  | Keystation61 MKII      | M-Audio Keystation61 MKII           |    | Keys |
| M Audio  | Axiom 61               | M-Audio Axiom 61                    |    | Keys |
| M Audio  | Axiom Pro 49           | M-Audio Axiom Pro 49                |    | Keys |
| M Audio  | Code 61                | M-Audio Code 61                     |    | Keys |
| M Audio  | Keystation88 MKII      | M-Audio Keystation88 MKII           |  | Keys |
| M Audio  | Oxygen 49MKV           | M-Audio Oxygen 49 MKV               |  | Keys |
| M Audio  | Oxygen 88              | M-Audio Oxygen 88                   |  | Keys |
| M-Audio  | SP2                    | M-Audio SP 2 Sustain Pedal          |  | Keys |
| Moog     | Grandmother            | Moog Grandmother 32                 |  | Keys |
| Moog     | Little Phatty Stage II | Moog Little Phatty Stage II         |  | Keys |
| Moog     | MOOG-SUB-37            | Moog Sub 37                         |  | Keys |
| Moog     | Sub phatty             | Moog Sub Phatty                     |  | Keys |
| Moog     | Subsequent 37          | Moog Subsequent 37                  |  | Keys |
| Moog     | Theremini              | Moog Theremini                      |  | Keys |

|                    |                          |                           |   |      |
|--------------------|--------------------------|---------------------------|---|------|
| Native Instruments | Komplete Kontrol S88 MK2 | Komplete Kontrol S88 MK2  |    | Keys |
| Nord               | 12033                    | Nord 12033 Triple Pedal 2 |    | Keys |
| Nord               | 12010                    | Nord 12010 Triple Pedal   |    | Keys |
| Nord               | 40265                    | Nord 40265 Sustain Pedal  |    | Keys |
| Nord               | C2D                      | Nord C2D                  |    | Keys |
| Nord               | C2D Pedal                | Nord C2D Pedal            |    | Keys |
| Nord               | Electro 3                | Nord Electro 3            |    | Keys |
| Nord               | Electro 4HP              | Nord Electro 4HP          |    | Keys |
| Nord               | Electro 5D               | Nord Electro 5D           |  | Keys |
| Nord               | Electro 5HP              | Nord Electro 5HP          |  | Keys |
| Nord               | 10866                    | Nord Electro 6D           |  | Keys |
| Nord               | 10846                    | Nord Grand 88             |  | Keys |
| Nord               | Half Moon Switch         | Nord Half Moon Switch     |  | Keys |
| Nord               | Lead 2X                  | Nord Lead 2X              |  | Keys |
| Nord               | Lead A1                  | Nord Lead A1              |  | Keys |
| Nord               | 10906                    | Nord Piano 5              |  | Keys |
| Nord               | Stage 2 EX88             | Nord Stage 2 EX88         |  | Keys |
| Nord               | Stage 2 HA76             | Nord Stage 2 HA76         |  | Keys |















|           |                  |                           |   |      |
|-----------|------------------|---------------------------|---|------|
| Nord      | Stage 2 HA88     | Nord Stage 2 HA88         |    | Keys |
| Nord      | STAGE 3          | Nord Stage 3              |    | Keys |
| Nord      | Stage 3 Compact  | Nord Stage 3 Compact      |    | Keys |
| Nord      | 10946            | Nord Stage 4 88           |    | Keys |
| Nord      | 10936            | Nord Stage 4 73           |    | Keys |
| Nord      | 10896            | Nord Wave 2               |    | Keys |
| Novation  | Bass Station II  | Novation Bass Station II  |    | Keys |
| Novation  | Impulse 25       | Novation Impulse 25       |    | Keys |
| Novation  | Impulse 61       | Novation Impulse 61       |  | Keys |
| Novation  | Launchkey 25 MK3 | Novation Launchkey 25 MK3 |  | Keys |
| Novation  | Launchkey 61     | Novation Launchkey 61     |  | Keys |
| Paul & Co | DMS-9x3          | Paul & Co DMS 9/3         |  | Keys |
| Roland    | A-49             | Roland A-49               |  | Keys |
| Roland    | Fantom 8         | Roland Fantom 8           |  | Keys |
| Roland    | A-88             | Roland A 88               |  | Keys |
| Roland    | A-88MKII         | Roland A 88 MKII          |  | Keys |
| Roland    | Alpha Juno 2     | Roland Alpha Juno 2       |  | Keys |
| Roland    | AX-Edge-B        | Roland AX Edge B          |  | Keys |


|        |             |                                  |   |      |
|--------|-------------|----------------------------------|---|------|
| Roland | AX-Synth    | Roland AX Synth                  |    | Keys |
| Roland | C-30        | Roland C 30                      |    | Keys |
| Roland | D-50        | Roland D 50                      |    | Keys |
| Roland | DP-10       | Roland DP 10 Sustain pedal       |    | Keys |
| Roland | DP-2        | Roland DP 2 Damper Sustain pedal |    | Keys |
| Roland | EA-7        | Roland EA7 61                    |    | Keys |
| Roland | EV-5        | Roland EV 5 Expression Pedal     |    | Keys |
| Roland | FA-06       | Roland FA 06                     |    | Keys |
| Roland | FA-08       | Roland FA 08                     |  | Keys |
| Roland | Fantom 6    | Roland Fantom 6                  |  | Keys |
| Roland | Fantom 7 EX | Roland Fantom 7 EX               |  | Keys |
| Roland | Fantom 7    | Roland Fantom 7                  |  | Keys |
| Roland | Fantom G6   | Roland Fantom G6                 |  | Keys |
| Roland | Fantom G7   | Roland Fantom G7                 |  | Keys |
| Roland | Fantom G8   | Roland Fantom G8                 |  | Keys |
| Roland | Fantom X7   | Roland Fantom X7                 |  | Keys |
| Roland | Fantom X8   | Roland Fantom X8                 |  | Keys |
| Roland | FP-50WH+ST  | Roland FP 50 WH+ST               |  | Keys |



|        |              |                     |   |      |
|--------|--------------|---------------------|---|------|
| Roland | FP-80BK      | Roland FP 80        |    | Keys |
| Roland | FP-90BK      | Roland FP 90BK      |    | Keys |
| Roland | FP50WH       | Roland FP 50        |    | Keys |
| Roland | FR-8X        | Roland FR 8X        |    | Keys |
| Roland | Gaia SH-01   | Roland Gaia SH-01   |    | Keys |
| Roland | GP-609PE     | Roland GP 609PE     |    | Keys |
| Roland | GP-609WH     | Roland GP 609WH     |    | Keys |
| Roland | JD-XA        | Roland JD-XA        |    | Keys |
| Roland | JD-Xi        | Roland JD-Xi        |  | Keys |
| Roland | Juno 106     | Roland Juno 106     |  | Keys |
| Roland | Juno 60      | Roland Juno 60      |  | Keys |
| Roland | Juno DS-88   | Roland Juno DS 88   |  | Keys |
| Roland | Juno Gi      | Roland Juno Gi      |  | Keys |
| Roland | Juno-X       | Roland Juno-X       |  | Keys |
| Roland | Jupiter 80   | Roland Jupiter 80   |  | Keys |
| Roland | Lucina AX-09 | Roland Lucina AX 09 |  | Keys |
| Roland | LX708-CH     | Roland LX708        |  | Keys |
| Roland | RD-2000      | Roland RD 2000      |  | Keys |

|                |                |                                    |   |      |
|----------------|----------------|------------------------------------|---|------|
| Roland         | RD-700NX       | Roland RD 700NX                    |    | Keys |
| Roland         | RD-800         | Roland RD 800                      |    | Keys |
| Roland         | RPU-3          | Roland RPU 3 3 way Pedal           |    | Keys |
| Roland         | SH-201         | Roland SH 201                      |    | Keys |
| Roland         | SYSTEM-8       | Roland SYSTEM-8                    |    | Keys |
| Roland         | V-Synth GT     | Roland V Synth GT                  |    | Keys |
| Roland         | VK-7           | Roland VK 7                        |    | Keys |
| Roland         | VP-770         | Roland VP-770                      |    | Keys |
| Roland         | V Combo VR-730 | Roland V Combo VR-730              |  | Keys |
| Roland         | VR-09B         | Roland VR-09B                      |  | Keys |
| Roland         | XP-80          | Roland XP 80                       |  | Keys |
| Roli           | Seaboard Block | Roli Seaboard Block                |  | Keys |
| Royal Standard | Marina         | Royal Standard Marina Accordion    |  | Keys |
| Sequential     | Prophet 6      | Sequential (DSI) Prophet 6         |  | Keys |
| Sequential     | Prophet X      | Sequential (DSI) Prophet X         |  | Keys |
| Stagg          | PB36 BKM SBK   | Stagg Matt Black Piano Bench       |  | Keys |
| Steinway       | D-274          | Steinway D-274 Concert Grand Piano |  | Keys |
| Studiologic    | VFP 1/15       | Studiologic VFP 1/15 Sustain Pedal |  | Keys |

|              |                               |   |   |      |
|--------------|-------------------------------|---|---|------|
| Vintage Vibe | VVP Wurlitzer Stacker         | Vintage Vibe Wurlitzer Stacker          |    | Keys |
| Moog         | Voyager Electric Blue Edition | Moog Voyager Electric Blue Edition      |    | Keys |
| Moog         | Voyager Performer Edition     | Moog Voyager Performer Edition          |    | Keys |
| Waldorf      | Iridium                       | Waldorf Iridium 49                      |    | Keys |
| Weltmeister  | Weltmeister                   | Weltmeister 80 Bass Accordion           |    | Keys |
| Weltmeister  | Meteor                        | Weltmeister Meteor 120 bass Accordion   |    | Keys |
| Weltmeister  | Stella                        | Weltmeister Stella Accordion            |    | Keys |
| Wurlitzer    | 200A                          | Wurlitzer 200A                          |    | Keys |
| Wurlitzer    | WURL-SP                       | Wurlitzer 200A Sustain pedal            |  | Keys |
| Yamaha       | ModX6+                        | Yamaha ModX6+                           |  | Keys |
| Yamaha       | C6X SH3                       | Yamaha C6X SH3 Grand Piano              |  | Keys |
| Yamaha       | C7X SH3                       | Yamaha C7X SH3 Semi-Concert Grand Piano |  | Keys |
| Yamaha       | CEL-56P                       | Yamaha CEL 56P Celesta                  |  | Keys |
| Yamaha       | CP-300                        | Yamaha CP 300                           |  | Keys |
| Yamaha       | CP-88                         | Yamaha CP-88                            |  | Keys |
| Yamaha       | CVP-609GP                     | Yamaha CVP 609GP                        |  | Keys |
| Yamaha       | ELS-02C                       | Yamaha ELS-02C                          |  | Keys |
| Yamaha       | FC-4                          | Yamaha FC 4 Sustain pedal               |  | Keys |

|        |             |  |   |      |
|--------|-------------|--|---|------|
| Yamaha | FC-7        | Yamaha FC 7 Volume Pedal               |    | Keys |
| Yamaha | FC-9        | Yamaha FC 9 Volume Pedal               |    | Keys |
| Yamaha | FC-3A       | Yamaha FC-3A Piano Style Sustain Pedal |    | Keys |
| Yamaha | FC-4A       | Yamaha FC-4A Piano Style Sustain Pedal |    | Keys |
| Yamaha | GC1 TA3     | Yamaha GC1 TA3 Baby Grand Piano        |    | Keys |
| Yamaha | ModX7       | Yamaha ModX7                           |    | Keys |
| Yamaha | ModX8       | Yamaha ModX8                           |    | Keys |
| Yamaha | Montage 6   | Yamaha Montage 6                       |    | Keys |
| Yamaha | Montage 7   | Yamaha Montage 7                       |  | Keys |
| Yamaha | Montage 8   | Yamaha Montage 8                       |  | Keys |
| Yamaha | Montage M7  | Yamaha Montage M7                      |  | Keys |
| Yamaha | Montage M8X | Yamaha Montage M8X                     |  | Keys |
| Yamaha | Motif ES-6  | Yamaha Motif ES 6                      |  | Keys |
| Yamaha | Motif ES-7  | Yamaha Motif ES 7                      |  | Keys |
| Yamaha | Motif XF-6  | Yamaha Motif XF 6                      |  | Keys |
| Yamaha | Motif XF-7  | Yamaha Motif XF 7                      |  | Keys |
| Yamaha | Motif XF-8  | Yamaha Motif XF 8                      |  | Keys |
| Yamaha | Motif XS-6  | Yamaha Motif XS 6                      |  | Keys |

---

|        |              |                             |   |      |
|--------|--------------|-----------------------------|---|------|
| Yamaha | Motif XS-7   | Yamaha Motif XS 7           |    | Keys |
| Yamaha | Motif XS-8   | Yamaha Motif XS 8           |    | Keys |
| Yamaha | N3-X         | Yamaha N3-X                 |    | Keys |
| Yamaha | P125B+ST+PD  | Yamaha P125B+ST+PD          |    | Keys |
| Yamaha | P125WH+ST+PD | Yamaha P125WH+ST+PD         |    | Keys |
| Yamaha | PSR-A2000    | Yamaha PSR A2000            |    | Keys |
| Yamaha | S90ES        | Yamaha S90ES                |    | Keys |
| Yamaha | S90XS        | Yamaha S90XS                |    | Keys |
| Yamaha | U1 SH3       | Yamaha U1 SH3 Upright Piano |  | Keys |

---

